





## Contents

Safety	2
Warnings	2
Symbols used in this manual	2
Operator's safety	2
Avoid filter module damage	2
DC-link resonance	2
Description	3
Description	3
Ordering numbers, 380 - 415 V, 50 Hz	4
Ordering numbers, 440 - 480 V, 60 Hz	5
Ordering numbers, 500 - 525 V, 50 Hz	5
Calculation of the exact filter size needed	6
Specifications	7
General technical data	7
Environmental data	7
Dimensions/weight	8
Dimension diagrams	10
Installation	13
Mechanical installation	13
Ventilation	13
Power wiring	13
Over temperature contactor	15
Power wiring size	15
Operation on different mains type	16
Typical installation in a panel or other enclosures	17
Commissioning	18
Commissioning	18
Appendix: Safety and application notes for	19
1. General	19
2. Application as directed	19
3. Transport, Storage	19
4. Installation	19
5. Electrial Installation	19
6. Operation	19
7. Maintenance and service	20
Index	21



#### Warnings



The Danfoss harmonic filter AHF 005 and AHF 010 contain dangerous voltages when connected to line voltages. Only a competent electrician should carry out the electrical installation. Improper installation of the filter module or the connected frequency converter may cause equipment failure, serious injury or death. Follow this manual and National Electrical Codes and local safety codes.

Operation of the harmonic filter is only allowed with a closed cover of the housing!

#### Symbols used in this manual

When you read this manual you will come across different symbols that require special attention. The symbols used are the following:



Warning of hazardous electrical voltage



Warning of a general danger



#### NB!

This note designates general, useful notes. If you observe it, handling of the filter module / drive system is made easier.

#### Operator's safety



After mains disconnections, the power terminals X1.1, X1.2, X1.3, X3.1, X3.2, X3.3, X4.1, X4.2 and X4.3 remain live for minimum 4 minutes.



The filter modules have to be installed in a way, that they fulfil their function and don't expose persons to danger. They have to be mounted correctly and used in accordance with their purpose.

#### • Avoid filter module damage

- The filter modules are to be used only with Danfoss frequency converters. The usage with other electrical loads is not permitted and may damage the devices.
- 2. Don't use the drive system (frequency converter, motor load and filter module) if the equipment has been damaged.
- 3. Modifications of the filter modules are not allowed.

#### DC-link resonance

To avoid resonance's in the DC-link, it is possible to disable the dynamic DC link compensation.

483	Dynamic DC link compensation	
	(DC link comp.)	
Value:		
Off		[0]
ি≉ On		[1]

## Function:

The VLT 5000, 6000 and 8000 series include a feature, which ensures that the output voltage is independent of any voltage fluctuation in the DC link, e.g. caused by fast fluctuation in the mains supply voltage. The benefit is a very steady torque on motor shaft (low torque ripple) under most mains conditions.

#### **Description of choice:**

In some cases this very dynamic compensation can cause resonance's in the DC link and should then be disabled. Typical cases are where a line choke or a passive harmonic filter (e.g. filters AHF005/010) is mounted in the mains supply to the frequency converter to suppress harmonics. Can also occur on mains with low short circuit ratio.



## Description

The Danfoss harmonic filters AHF 005 and AHF 010 are ensuring near sinusoidal line current minimising the harmonic current emission into the mains supply. The Danfoss AHF 005 and AHF 010 are advanced harmonic filters not to be compared with traditional harmonic trap filters. The Danfoss harmonic filters have been specially designed to match all the Danfoss frequency converters. The filters AHF 010 and AHF 005 are available in four voltage ratings.

- 380 415 V AC, 50 Hz
- 440 480 V AC, 60 Hz
- 500 525 V AC, 50 Hz
- 690 V AC, 50 Hz

The Danfoss AHF 010 and AHF 005 have the following characteristics:

- Small compact housing that fits into a panel
- Easy to use in retrofit applications
- AHF 010 reduces the total harmonic current distortion to 10%\*
- AHF 005 reduces the total harmonic current distortion to 5%\*
- Current rating from 10A 370A
- For higher power modules can be paralleled
- One filter module can be used for several frequency converters
- High efficiency (> 0.98)
- User-friendly commissioning no adjustment necessary
- No routine maintenance required

\* THiD of 10% or 5% will be achieved when the following conditions are met:

- THvD of the system without the drive operating is less than 2%
- Filter is operating at nominal load

If these conditions are not fulfilled, a significant reduction of the harmonic components can still be achieved, but the rated THiD values may not be achieved.



## Principle connection diagram of the Danfoss harmonic filter.

Legends (as used throughout this manual):

U∟:	Line voltage
I <sub>AHF</sub> :	Input current of the filter
	AHF
I <sub>FC,L</sub> :	Input current to the fre-
	quency converter
IM:	Motor current



## ■ Ordering numbers, 380 - 415 V, 50 Hz

IAHF,N	Typical Motor	Danfoss ordering number		Typical Danfoss frequency converter series •			
	Used [kW]	AHF 005	AHF 010	VLT 5000	VLT 6000 HVAC	<b>VLT 8000 AQUA</b>	
10 A	4, 5.5	175G6600	175G6622	5006, 5008	6006, 6008	8006, 8008	
19 A	7.5	175G6601	175G6623	5011	6011	8011	
26 A	11	175G6602	175G6624	5016	6016	8016	
35 A	15, 18.5	175G6603	175G6625	5022, 5027	6022, 6027	8022, 8027	
43 A	22	175G6604	175G6626	5032	6032	8032	
72 A	30, 37	175G6605	175G6627	5042, 5052	6042, 6052	8042, 8052	
101 A	45, 55	175G6606	175G6628	5062, 5072	6062, 6072	8062, 8072	
144 A	75	175G6607	175G6629	5102	6102	8102	
180 A	90	175G6608	175G6630	5122	6122	8122	
217 A	110	175G6609	175G6631	5152	6152	8152	
289 A	132, 160	175G6610	175G6632	5202, 5252	6172, 6222	8202, 8252	
324 A		175G6611	175G6633				
370 A	200	175G6688	175G6691	5302	6272	8302	
Higher ratings car	be achieved by pa	ralleling the filter ur	nits				
434 A	250	Two 21	7A units	5352	6352	8352	
578 A	315	Two 289	9 A units	5452	6402	8452	
613 A	355	289 A and	324 A units	5502	6502	8502	
648 A	400	Two 324	4 A units		6552	8602	

## AHF 005 and AHF 010, 380V - 415V, 50Hz

• Please note that the matching of the typical Danfoss frequency converter and filter is pre-calculated based on 400V and assuming typical motor load (4 or 2 pole motor). VLT 5000 series is based on a max. 160 % torque application, while VLT 6000 and 8000 series are based on a max. 110% torque application.

The pre-calculated filter current may be different than the input current ratings of VLT 5000, VLT 6000 and VLT 8000 series as stated in the respective operating instructions, as these numbers are based on different operating conditions.

I <sub>AHF,N</sub>	Typical Motor	Danfoss ordering	Danfoss ordering number		Typical Danfoss frequency converter series •			
	Used [HP]	AHF 005	AHF 010	VLT 5000	VLT 6000 HVAC	<b>VLT 8000 AQUA</b>		
19 A	10, 15	175G6612	175G6634	5011, 5016	6011, 6016	8011, 8016		
26 A	20	175G6613	175G6635	5022	6022	8022		
35 A	25, 30	175G6614	175G6636	5027, 5032	6027, 6032	8027, 8032		
43 A	40	175G6615	175G6637	5042	6042	8042		
72 A	50, 60	175G6616	175G6638	5052, 5062	6052, 6062	8052, 8062		
101 A	75	175G6617	175G6639	5072	6072	8072		
144 A	100, 125	175G6618	175G6640	5102, 5122	6102, 6122	8102, 8122		
180 A	150	175G6619	175G6641	5152	6152	8152		
217 A	200	175G6620	175G6642	5202	6172	8202		
289 A	250	175G6621	175G6643	5252	6222	8252		
324 A	300	175G6689	175G6692	5302	6272	8302		
370 A	350	175G6690	175G6693	5352	6352	8352		
Higher ratings can	be achieved by pa	ralleling the filter ur	nits					
506 A	450	217 A and	289 A units	5452	6402	8452		
578 A	500	Two 289	Two 289 A units		6502	8502		
648 A	600	Two 324	4 A units	-	6552	8602		

#### Ordering numbers, 440 - 480 V, 60 Hz

• Please note that the matching of the typical Danfoss frequency converter and filter is pre-calculated based on 480V and assuming typical motor load. VLT 5000 series is based on a 160 % torque application, while VLT 6000 and 8000 series are based on 110% torque application.

The pre-calculated filter current may be varying from the input current ratings of VLT 5000, VLT 6000 and VLT 8000 series as stated in the respective operating instructions, as these numbers are based on different operating conditions.

IAHF,N	Typical Motor	Danfoss ordering number		Typical Danfoss frequency converter series •			
	Used [kW]	AHF 005	AHF 010	VLT 5000	VLT 6000 HVAC	<b>VLT 8000 AQUA</b>	
10 A	4, 5.5	175G6644	175G6656	5006, 5008	6006, 6008	8006, 8008	
19 A	7.5, 11	175G6645	175G6657	5011, 5016	6011, 6016	8011, 8016	
26 A	15, 18.5	175G6646	175G6658	5022, 5027	6022, 6027	8022, 8027	
35 A	22	175G6647	175G6659	5032	6032	8032	
43 A	30	175G6648	175G6660	5042	6042	8042	
72 A	37, 45	175G6649	175G6661	5052, 5062	6052, 6062	8052, 8062	
101 A	55, 75	175G6650	175G6662	5062, 5072	6062, 6072	8062, 8072	
144 A	90, 110	175G6651	175G6663	5102, 5122	6102, 6122	8102, 8122	
180 A	132	175G6652	175G6664	5152	6152	8152	
217 A	160	175G6653	175G6665	5202	6172	8202	
289 A	200	175G6654	175G6666	5252	6222	8252	
324 A	250	175G6655	175G6667	5302	6302	8302	
Higher ratings can be achieved by paralleling the filter units							
434 A	315	Two 217	7 A units	5352	6352	8352	
469 A	355	180 A and	289 A units	5452	6402	8452	
578 A	400	Two 289	9 A units	5502	6502	8502	

## Ordering numbers, 500 - 525 V, 50 Hz

• Please note that the matching of the typical Danfoss frequency converter and filter is pre-calculated based on 500V and assuming typical motor load. VLT 5000 series is based on a 160 % torque application, while VLT 6000 and 8000 series are based on 110% torque application.

The pre-calculated filter current may be varying from the input current ratings of VLT 5000, VLT 6000 and VLT 8000 series as stated in the respective operating instructions, as these numbers are based on different operating conditions.

I <sub>AHF,N</sub>	Typical Motor Used [kW]	Danfoss ordering number		Typical Danfoss frequency converter series •		
		AHF 005	AHF 010	VLT 5000 160 %	VLT 8000 HVAC	
43 A	37, 45	130B2328	130B2293	5042, 5052	8052	
72 A	55, 75	130B2330	130B2295	5062, 5072	8062, 8072	
101 A	90	130B2331	130B2296	5102	8102	
144 A	110, 132	130B2333	130B2298	5122, 5152	8122, 8152	
180 A	160	130B2334	130B2299	5202	8202	
217 A	200	130B2335	130B2300	5252	8252	
289 A	250	130B2331 & 130B2333	130B2301	5302	8302	
324 A	315	130B2333 & 130B2334	130B2302	5352	8352	
370 A	400	130B2334 & 130B2335	130B2304		8402	

#### Ordering numbers, 690 V 50 Hz

• Please note that the matching of the typical Danfoss frequency converter and filter is pre-calculated based on 500V and assuming typical motor load. VLT 5000 series is based on a 160 % torque application, while the VLT 8000 series are based on 110% torque application.

The pre-calculated filter current may be varying from the input current ratings of VLT 5000 and VLT 8000 series as stated in the respective operating instructions, as these numbers are based on different operating conditions.

#### Calculation of the exact filter size needed

For optimal performance the harmonic filter should be sized for the line input current to the frequency converter, i.e. the input current drawn based on the expected load of the frequency converter and not the size of the frequency converter itself!

The line input current to the frequency converter (I<sub>FC,L</sub>) can by calculated using the nominal motor current (I<sub>M,N</sub>) and displacement power factor (Cos  $\varphi$ )) of the motor. Both data are normally printed on the nameplate of the motor. In the case where the nominal motor voltage (U<sub>M,N</sub>) is unequal to the actual line-line voltage (U<sub>L</sub>) the calculated current must be corrected with the ratio between these voltages as shown in the equation below.  $I_{F^{\phi},L} = 1.1 * I_{M,N} * Cos(\varphi) * ((U_{M,N})/(U_L))$ The harmonic filter chosen must have a nominal cur-

rent ( $I_{AHF,N}$ ) equal to or larger than the calculated frequency converter line input current ( $I_{FC,L}$ ).

If several frequency converters are to be connected to the same filter, the harmonic filter must be sized according to the sum of the calculated line currents.



If the harmonic filter is sized for the load, and the motor of the corresponding frequency converter is changed, the current must be re-calculated to avoid overload of the harmonic filter.

#### General technical data

		1				
		AHF 0xx	AHF 0xx	AHF 0xx	AHF 0xx	
Nominal supply	U <sub>L,N</sub> [V]	$380 \le U_{L,N} \le 415$	$440 \leq U_{L,N} \leq 480$	500 - 525 V	690 V	
voltage						
Tolerance of the	$U_{L}[V]$	$342 \le U_L \le 456$	396 ≤ U <sub>L</sub> ≤ 528	450 ≤ U <sub>L</sub> ≤ 577	621 ≤ U <sub>L</sub> ≤ 759	
actual supply volt-						
age						
Supply frequency	f <sub>L,N</sub> [Hz]	50 ± 5 %	60 ± 5 %	50 ± 5 %	50 ± 5 %	
Overload capabil-			1,6 fc	or 60s		
ity						
Efficiency	η[%]		~ 98	.8 %		
THiD	[%]		AHF 00	)5 < 5%		
			AHF 010	0 < 10%		
$\cos \phi$ of $I_L$		0.5 cap	at 25% I <sub>AHF,N</sub>			
		0.8 cap	at 50% IAHF,N			
		0.85 cap	at 75% I <sub>AHF,N</sub>			
		0.99 cap	at 100% I <sub>AHF,N</sub>			
		1.00	at 150% І <sub>АНF,N</sub>			
Power derating	[%/C]	40°C < Ta < 55°C => 3%/C				
	[%/m]	1000m altitude above sea level.< h ≤ 4000m altitude				
		above sea level => $5\%/1000$ m				



## NB!

The reduction of the low harmonic current emission to the rated THiD implies, that the THvD of the non-influenced mains voltage is lower than 2% and the ratio of short circuit power to installed load (R SCE ) is at least 66. Under these conditions the THiD of the mains current of the frequency converter is reduced to 10% or 5% (typical values at nominal load). If these conditions are not or only partially fulfilled, a significant reduction of the harmonic components can still be achieved, but the rated THiD values may not be achieved.

## Environmental data

Permissible	During transport of the unit:	-25°C+70°C (to VDE 0160)
temperature range*	During storage of the unit:	-25°C+55°C (to VDE 0160)
	During operation of the unit:	5°C+40°C without power derating
		5°C+55°C with power derating
Humidity class*	Humidity class F without condensati	ation ( 5% - 85% relative humidity)
Installation height h*	H ≤ 1000 m altitude above sea lev	el without power derating
	1000 m altitude above sea level	< h ≤ with power derating
	4000 m altitude above sea level	
Degree of pollution	VDE 0110 Part 2 degree 2	
Insulation strength	Overvoltage category III according	to VDE 0110
Packaging	DIN 55468 for transport packaging	materials
Type of protection	IP 20	
Approvals	CE: Low-Voltage Directive; UL; C-	tick

\*climatic conditions according to class 3K3 (EN 50178 Part 6.1)

Danfoss

## Dimensions/weight

The AHF modules are available in seven frame sizes (size B to H). For dimensions see the drawings on the following pages

AHF 005, 380 – 415 V AC, 50Hz		AHF 010, 380– 415 V AC, 50Hz			
IAHF,N	Frame size	Weight	IAHF,N	Frame	Weight
				size	
10 A	В	20 Kg (44 lbs)	10 A	В	15 Kg (33 lbs)
19 A	С	31 Kg (68 lbs)	19 A	В	19 Kg (42 lbs)
26 A	С	31 Kg (68 lbs)	26 A	В	24 Kg (52 lbs)
35 A	С	49 Kg (108 lbs)	35 A	С	38 Kg (84 lbs)
43 A	D	60 Kg (132 lbs)	43 A	С	45 Kg (99 lbs)
72 A	D	81 Kg (178 lbs)	72 A	D	64 Kg (141 lbs)
101 A	E	128 Kg (282 lbs)	101 A	D	80 Kg (176 lbs)
144 A	E	165 Kg (364 lbs)	144 A	D	101 Kg (222 lbs)
180 A	F	197 Kg (434 lbs)	180 A	E	134 Kg (295 lbs)
217 A	F	228 Kg (503 lbs)	217 A	E	159 Kg (350 lbs)
289 A	G	269 Kg (593 lbs)	289 A	F	180 Kg (396 lbs)
324 A	G	309 Kg (681 lbs)	324 A	F	233 Kg (513 lbs)
370 A	Н	345 Kg (760 lbs)	370 A	G	252 Kg (555 lbs)

AHF 005, 440 – 480 V AC, 60Hz		AHF 010, 440 – 480 V AC, 60Hz			
I <sub>AHF,N</sub>	Frame	Weight	I <sub>AHF,N</sub>	Frame size	Weight
	size				
19 A	С	32 kg (71 lbs)	19 A	В	20 kg (44 lbs)
26 A	С	43 kg (95 lbs)	26 A	В	25 kg (55 lbs)
35 A	С	50 kg (110 lbs)	35 A	С	38 kg (84 lbs)
43 A	D	60 kg (132 lbs)	43 A	С	45 kg (99 lbs)
72 A	D	82 kg (181 lbs)	72 A	D	64 kg (141 lbs)
101 A	E	129 kg (284 lbs)	101 A	D	81 kg (178 lbs)
144 A	E	167 kg (368 lbs)	144 A	D	103 kg (227 lbs)
180 A	F	200 kg (441 lbs)	180 A	E	135 kg (297 lbs)
217 A	F	230 kg (507 lbs)	217 A	E	161 kg (355 lbs)
289 A	G	272 kg (600 lbs)	289 A	F	191 kg (421 lbs)
324 A	G	306 kg (675 lbs)	324 A	F	232 kg (511 lbs)
370 A	Н	348 kg (767 lbs)	370 A	G	245 kg (540 lbs)

AHF 005, 500 - 525 V AC, 50Hz			AHF 010, 500 - 525 V AC, 50Hz		
I <sub>AHF,N</sub>	Frame	Weight	I <sub>AHF,N</sub>	Frame size	Weight
	size				
10 A	В	22 Kg (48 lbs)	10 A	В	17 Kg (37 lbs)
19 A	С	35 Kg (77 lbs)	19 A	В	21 Kg (46 lbs)
26 A	С	49 Kg (108 lbs)	26 A	В	28 Kg (62 lbs)
35 A	С	55 Kg (121 lbs)	35 A	С	42 Kg (93 lbs)
43 A	D	67 Kg (147 lbs)	43 A	D	47 Kg (104 lbs)
72 A	E	82 Kg (181 lbs)	72 A	D	69 Kg (152 lbs)
101 A	E	144 Kg (317 lbs)	101 A	D	91 Kg (200 lbs)
144 A	E	187 Kg (412 lbs)	144 A	E	131 Kg (289 lbs)
180 A	F	226 Kg (498 lbs)	180 A	E	147 Kg (324 lbs)
217 A	F	262 Kg (578 lbs)	217 A	F	185 Kg (408 lbs)
289 A	G	309 Kg (681 lbs)	289 A	F	209 Kg (461 lbs)
324 A	G	348 Kg (767 lbs)	324 A	G	256 Kg (564 lbs)



AHF 005, 690V AC, 50Hz			AHF 010, 690 V AC, 50Hz		
I <sub>AHF,N</sub>	Frame	Weight	I <sub>AHF,N</sub>	Frame size	Weight
	size				
43 A	D	85 kg (187 lbs)	43 A	D	65 kg (143 lbs)
72 A	E	100 kg (220 lbs)	72 A	D	75 kg (165 lbs)
101 A	F	130 kg (287 lbs)	101 A	E	95 kg (209 lbs)
144 A	G	160 kg (353 lbs)	144 A	E	125 kg (275 lbs)
180 A	G	200 kg (441 lbs)	180 A	F	140 kg (309 lbs)
217 A	Н	300 kg (661 lbs)	217 A	G	180 kg (397 lbs)
			289 A	G	200 kg (441 lbs)
			324 A	Н	250 kg (551 lbs)
			370 A	Н	300 kg (661 lbs)





# Danfoss

## AHF 005/010

#### Frame size E



## Frame size F



#### Frame size G

Specifications







## NB!

Please allow an additional 30 mm of depth of the filter for the mounting feet.



## Mechanical installation

The encapsulation of the filters have an IP 20 rating. The modules can be mounted side by side with 60mm (2,36 inches) clearance.

To other components and to the cabinet walls keep a horizontal clearance of at least 70mm (2,76 inches) and a vertical clearance of at least 150mm (5,91 inches).

Only vertical installation is allowed (mains terminal at bottom).



For versions with bus bars (frame size E – H) it is necessary to mount the added covers to the connectors in order to achieve the protection type IP 20.



175HA500.10

## Ventilation

The filters are cooled by means of air circulation. Consequently, the air needs to be able to move freely above and below the filter module. The efficiency of the filter modules is greater than 0.98. When installing a filter module in a panel or another enclosure, ensure there is sufficient airflow though the enclosure to limit heat rise in the enclosure.

	AHF 0xx, 380 – 415V	AHF 0xx, 440 – 480V	AHF 0xx, 500V - 525V	AHF 0xx, 690V
	Max. Heat	Max. Heat	Max. Heat	Max. Heat
10 A	83 W		104 W	
19 A	158 W	190 W	197 W	
26 A	216 W	259 W	270 W	
35 A	290 W	349 W	364 W	
43 A	358 W	429 W	447 W	617 W
72 A	599 W	718 W	748 W	1033 W
101 A	840 W	1008 W	1050 W	1448 W
144 A	1197 W	1437 W	1496 W	2065 W
180 A	1496 W	1796 W	1871 W	2581 W
217 A	1804 W	2165 W	2255 W	3112 W
289 A	2403 W	2883 W	3003 W	4145 W
324 A	2694 W	3232 W	3367 W	4646 W
370 A	3076 W	3691 W		5306 W



#### NB!

If other heat sources (e.g. Danfoss frequency converters) are installed in an enclosure with the harmonic filter AHF 0xx, this heat generation must also be considered when calculating required airflow



## NB!

If the cooling air is polluted (dust, dirt swirl, grease, aggressive gas) the function of the filter module may be impeded. Ensure sufficient countermeasures, e.g. separate cooling air, mounting of air filters, periodical cleaning.

## Power wiring

## **Standard connection**

Supply voltage must be connected to the terminals X1.1, X1.2 and X1.3. The frequency converter supply

terminals L1, L2 and L3 must be connected to the filter module terminals X2.1, X2.2 and X2.3.



## Paralleling of FC's

If several frequency converters are to be connected to the harmonic filter, the connection is similar to the standard connection - The supply terminals L1, L2 and L3 of several frequency converters must be connected to the filter module terminals X2.1, X2.2 and X2.3.



## NB!

If several FC's are to be connected to the same filter, the harmonic filter must be sized according to the sum of the calculated input current to the FC's.

## Paralleling of filters

If the line input current of the frequency converter exceeds the nominal current of the largest harmonic filter, several harmonic filters can be paralleled to achieve the necessary rating. Supply voltage must be connected to the terminals X1.1, X1.2 and X1.3 of the filters. The frequency converter supply terminals L1, L2 and L3 must be connected to the filter modules terminals X2.1, X2.2 and X2.3.



#### NB!

Filters of different current ratings can be paralleled. The rating of the filter becomes the sum of the individual current ratings.

## **Capacitor disconnect**

The power factor of the harmonic filter AHF 005/010 is decreasing with decreasing load. At zero load the Power Factor becomes zero and the capacitors produce approximately 30% leading current compared to the rated current of the filter. The reactive current generated by the filter at partial load is normally not of any concern, mainly because of the small current compared to the system capacity (max 30%) as well as the fact that other load normally compensates the capacitive current.

In applications where this reactive current may not be accepted, Terminals X3.1, X3.2, X3.3 and X4.1, X4,

X4.3 are giving acces to the filter capacitors. As default (on delievery) the wiring will shorten Terminal X3.1 with X4.1, X3.2 with X4.2 and X3.3 with X.4.3. In the case of that no capacitor disconnect is required no changes should be made. If capacitor disconnecet is required a three-phase contactor should be placed between terminals X3 and X4. Size the contactor and wiring to 50% of the nominal current and use the AC3 rating of the contactor.



## NB!

Only switch the contactor at less than 20% output power. Allow minimum 240 seconds for the capacitors to discharge before turning on again.



<u>Use cables complying with local regula-</u> tions.



## Over temperature contactor

The Danfoss harmonic filter AHF 005 and AHF 010 is equipped with a galvanic isolated contactor that is closed under normal operating conditions and open if the filter is overheated. This contactor must be used to prevent damages to the filter caused by over temperature as shown in the following example.



NB!

Example: Connect terminal A of the harmonic filter to terminal 12 or13 (voltage supply digital input, 24V) of the Danfoss frequency converter and terminal B to terminal 27 (digital input "Coast Inverse") the frequency converter will let go of the motor (coasting) and thereby unload the filter if a over temperature is detected.



The maximum rating of the over temperature contactor is 250V AC and 10A.

#### Power wiring size

#### Power wiring size

Enclosure	Max. cable size mm <sup>2</sup>	AWG	Туре	Nom. Fix Torque
В	16	6	Connector	2 Nm
C and D	50	1	Connector	6 Nm
E, F, G and H	*	*	Bus Bars	25 Nm

## Overheat contactor (copper)

Enclosure	Max. cable size mm <sup>2</sup>	AWG	Туре	Nom. Fix Torque
	4		Connector	0.6 Nm

#### Capacitor disconnect (copper)

Enclosure	Max. cable size mm <sup>2</sup>	AWG	Туре	Nom. Fix Torque
В	4	10	Connector	0.6 Nm
C and D	16	6	Connector	2 Nm
E, F, G and H	50	1	Connector	6 Nm

\*Power wiring used for connection of the filter AHF 005 and AHF 010 in enclosure size E, F and G must be terminated with cable lugs that can be attached to the input and output bus bars terminals. This type of termination imposes no specifications of the minimum and maximum cable size suitable for connection. Power terminal details regarding the bus bars can be found in the figures below.











NB! For UL approval use copper conductor only.

## Operation on different mains type

Mains type		Operation of the filter module	
TN	Directly grounded star point	Allowed	
TN	Indirectly grounded star point	Allowed	
IT	Isolated star point	Allowed	

The filter module has been designed completely symmetrically for three phase operation and without reference to the star point or protective earth.



- Typical installation in a panel or other enclosures To avoid high frequency noise coupling keep a minimum distance of 150 mm (5.91 inches) to:
  - a) mains/supply wires
  - b) motor wires of frequency converter
  - c) control- and signal wires (voltage range < 48 V)

To obtain low resistive HF-connections, grounding, screening and other metallic connections (e. g. mounting plates, mounted units) should have a surface as large as possible to metallic ground. Use grounding and potential equalisation wires with a cross section as large as possible (min. 10mm<sup>2</sup>) or thick grounding tapes.

Use copper or tinned copper screened wires only, as steel screened wires are not suitable for high frequency applications. Connect the screen with metal clamps or metal glands to the equalisation bars or PE-connections.

Inductive switching units (relay, magnetic contactor etc.) must always be equipped with varistors, RC-circuits or suppressor diodes.



- 1. Panel
- 2. Mains supply wire
- 3. Motor wiring
- 4. Control wiring
- 5. Wiring between harmonic filter and frequency converter
- 6. Mains supply wire of filter module
- 7. Mounting plate (common star point)
- 8. Potential equalisation
- 9. Filter module AHF 0xx
- 10. Mains connection
- 11. PLC
- 12. Frequency converter
- 13. Mains fuses
- 14. Mains circuit breaker

Danfoss

## Commissioning



Prior to initial switch-on of the filter module check the wiring for completeness, shortcircuit and earth fault.



If the wiring is not correct, a non-intended operation of controller and/or filter module is possible.

## First powering up

- Switch on mains supply :

   The filter module is ready for operation at once.
- 2. Check the readiness of the frequency converter:

- Proceed in accordance with the operating instructions of the frequency converter.



## 1. General

During operation, filter modules unit may have, according to their type of protection, live, bare, in some cases also movable or rotating parts as well as hot surfaces.

Non - authorized removal of required cover, inappropriate use, incorrect installation or operation, creates the risk of severe injury to persons or damage to material assets.

Further information can be obtained from the documentation.

All operations concerning transport, installation and commissioning as well as maintenance must be carried out by qualified, skilled personnel (IEC 364 and CENELEC HD 384 or DIN VDE 0100 and IEC-Report 664 or DIN VDE 0110 and national regulations for the preventions of accidents must be observed).

According to this basic safety information qualified skilled personnel are persons who are familiar with the erection, assembly, commissioning and operation of the product and who have the qualifications necessary for their occupation.

## 2. Application as directed

Filter modules are components, which are designed for installation in electrical systems or machinery.

When installing in machines, commissioning of the filter modules (i.e. the starting of operation as directed) is prohibited until it is proven, that the machine corresponds to the regulations of the EC Directive 83/392/ EEC (Machinery Directive); EN 60204 must be observed.

Commissioning (i.e. starting operation as directed) is only allowed when there is compliance with the EMC-Directive 89/336/EEC.

The filter modules meet the requirements of the Low-Voltage Directive 73/23/EEC. The technical data and information on the connection conditions must be obtained from the nameplate and the documentation and must be observed in all cases.

#### 3. Transport, Storage

Notes on transport, storage and appropriate handling must be observed.

The filter modules have to be protected from inadmissible stress. In particular during transport and handling no components are allowed to be bend and / or isolating distances may not be altered. The units are equipped with electrostatic sensitive devices, which may be damaged by improper handling. Therefore it has to be avoided to get in contact with electronic components. If electronic components are damaged mechanically the unit must not be put into operation, as it cannot be ensured, that all relevant standards are observed. Climatic conditions must be observed according to prEN 50178.

#### 4. Installation

The devices must be erected and cooled according to the regulations of the corresponding documentation.

The filter modules must be protected from inappropriate loads. Particularly during transport and handling, components must not be bent and / or isolating distances must not be changed. Touching of electronic components and contacts must be avoided.

Filter modules contain electro-statically sensitive components, which can easily be damaged by inappropriate handling. Electrical components must not be damaged or destroyed mechanically (health risk are possible!).

#### 5. Electrial Installation

When working on live filter modules, the valid national regulations for the prevention of accidents (e.g. VBG 4) must be observed. Before any installation or connection works, the plant has to be switched off and to be secured properly.

The electrical installation must be carried out according to the appropriate regulations (e.g. cable crosssections, fuses, PE-connection). More detailed information is included in the documentation. When using the filter module with frequency converters without safe separation from the supply line (to VDE 0100) all control wiring has to be included in further protective measures (e.g. double insulated or shielded, grounded and insulated).

#### 6. Operation

Systems where filter modules are installed, if applicable, have to be equipped with additional monitoring and protective devices according to the valid safety regulations e.g. law on technical tools, regulations for the prevention of accidents, etc.

After disconnecting the filter module from the supply voltage, live parts of the filter module and power con-

Danfoss

nections must not be touched immediately, because of possibly charged capacitors.

During operation, all covers and doors must be closed.

## 7. Maintenance and service

The manufacturer's documentation must be observed.

## This safety information must be kept!

The product-specific safety and application notes in these Operating Instructions must also be observed!

Danfoss

Index





## www.danfoss.com/drives

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

175R0932

MG80B502



Rev. 2006-08-28